

MUTE TUBE

ASSEMBLY INSTRUCTIONS


Model: TF500S315-G7





PACKAGE CONTENTS

1x Music Holder



1x Support



2x Rubber Seal



1x MUTE TUBE



1x Inclination Adapter



4x Screws M5




1x Stand-Tripods





ARRANGEMENT OF ITEMS

Music Holder



MUTE TUBE



Inclination Adapter




Stand-Tripods





MOUNTING THE MUSIC HOLDER





MOUNTING THE MUSIC HOLDER


Remove the screw cap and put 1 or 2 rubber seals (depending on position and stability) over the screw.



The support for the music holder is screwed to the top of the MUTE TUBE with the M12 screw and pressed with the rubber ring.




The music holder can be fixed at sight with a locking screw. The inclination angle is adjustable.





MOUNTING THE IMG INCLINATION ADAPTER





MOUNTING THE IMG INCLINATION ADAPTER



A mounting plate on the underside of the MUTE-TUBE is equipped with M5 threaded holes at each corner.



The IMG inclination adapter can be screwed to the 4 mounting holes with the mounting plate.





MOUNTING THE STAND





[OPTIONAL] INSTALLING A MICROPHONE

A 3/8" screw for microphone holder and a 3 pin microphone connector (XLR / XLR, Male / Female) is located at the bottom of the interior.

For recordings it is possible to attach a microphone and a microphone holder. The microphone connector can be connected to any XLR microphone cable both inside and outside.

